



# Cooling

at operation start



Prevents cold air from falling

at stable operation



# Heating

Prevents cold draft from window

at stable operation

